# STARHUB Universal Remote Control
User Guide

## 1. Controlling your home devices

The StarHub Universal Remote Control allows you to control your TV set and DVD player. It supports up to 678 brands of TV and 230 brands of DVD players. To use the remote control for your other devices, you will need to program the TV and DVD mode keys to control the relevant device listed in Section A. Please refer to the TV & DVD Setup Code List found in Section A for a list of supported brands and models. If you do not see your device brand listed in the TV & DVD Setup Code List you can follow the relevant Auto Search steps to auto search the relevant device.

## 2. To operate your devices

To operate your StarHub device press the STARHUB (USE THE STARHUB ICON) button. To operate your TV, press the TV button. To operate your DVD player press the DVD button.

## 3. To Control your TV device

To program the ID code for a particular brand of TV follow the sequence below:

1. Switch on the TV you wish to control with the remote control
2. Press and hold both the TV and OK keys.
3. Release both the TV mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate setup mode.
5. Look out for the 4-digit code of your TV set in TV & DVD Setup Code List and enter them by pressing the number keys on your remote control
6. After the fourth key has been entered, the TV mode LED will blink 3 times to indicate a successful configuration.

   If an invalid code has been entered the, ALL the mode LEDs will flash once to indicate unsuccessful configuration.

   If you are unsuccessful in the configuration repeat the steps to configure the remote control again.
7. Should you wish to program a different TV device to this remote control, repeat Steps 1-6 again with the selected TV.

## 4. TV auto-search function

To automatically search for your TV device, follow the auto-search steps as described below:

1. Switch on the TV you wish to control with the remote control
2. Press and hold both the TV and OK keys.
3. Release both the TV mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate successful entry into the current setup.
5. Enter the auto-search setup code 9 – 2 – 2
6. After the third key has been released, the TV mode LED will give 2 short blinks to indicate it is in auto-search mode.
7. Press and hold the PLAY key to activate the auto search. The remote control will now automatically go through its database of TV codes to search for a relevant TV device.
8. If the selected TV device responds by turning off the power, this means that auto-search has found the correct code for your TV device. Immediately release the PLAY key and press the OK key.
9. After the OK key has been released, the TV mode LED will blink 3 times to indicate successful configuration.
10. To exit the auto search mode without configuring the TV device, Press the EXIT key. After the EXIT key has been released, the TV mode LED will blink 3 times to indicate it has exited auto-search mode.

## 5. To control your DVD player

To program the ID code for a particular brand of DVD follow the sequence below:

1. Switch on the DVD player you wish to control with the remote control.
2. Press and hold both the DVD and OK keys.
3. Release both the DVD mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate setup mode.
5. Look out for the 4-digit code of your DVD player in TV & DVD Setup Code List and enter them by pressing the number keys on your remote control.
6. After the fourth key has been entered, the DVD mode LED will blink 3 times to indicate a successful configuration.

   If an invalid code has been entered, ALL the mode LEDs will flash once to indicate unsuccessful configuration.

   If you are unsuccessful in the configuration repeat the steps to configure the remote control again.
7. Should you wish to program a different DVD player to this remote control, repeat Steps 1-6 with the selected DVD player.

## 6. DVD auto-search function

To automatically search for your DVD Player, follow the auto-search steps as described below

1. Switch on the DVD you wish to control with the remote control.
2. Press and hold both the DVD and OK keys.
3. Release both the DVD mode key and OK key.
4. All of the mode keys will give 2 short blinks to indicate successful entry into the current setup.
5. Enter the auto-search setup code 9 – 2 – 2
6. After the third key has been released, the DVD mode LED will give 2 short blinks to indicate it is in auto-search mode.
7. Press and hold the PLAY key to start the auto-search mode. The remote control will now automatically go through its database of DVD codes to search for a relevant DVD player.
8. If the selected DVD device responds by turning off the power, this means that auto-search has found the correct code for your DVD device. Immediately release the PLAY key and press the OK key.
9. After the OK key has been released, the DVD mode LED will blink 3 times to indicate successful configuration.
10. To exit without configuring the DVD device, Press the EXIT key. After the EXIT key has been released, the DVD mode LED will blink 3 times to indicate it has exiited auto-search mode.

## 7. TV & DVD Setup Code List

### TV CODES

| | |
|---|---|
| **Number** | |
| 888 | 0183 |
| **A** | |
| A.R. Systems | 0134 |
| ACE | 0170 |
| Acme | 0002 |
| Acura | 0004, 0032 |
| ADA | 0003 |
| ADC | 0001 |
| Admiral | 0000, 0001, 0008, 0009, 0015, 0043 |
| Adyson | 0002, 0048, 0049, 0070 |
| Agashi | 0048, 0070 |
| Agazi | 0001 |
| AGB | 0073 |
| Aiko | 0002, 0004, 0032, 0036, 0041, 0048, 0049, 0070, 0134 |
| Aim | 0134 |
| Akai | 0003, 0004, 0014, 0024, 0026, 0028, 0032, 0036, 0041, 0048, 0049, 0050, 0068, 0070, 0073, 0108, 0134 |
| Akiba | 0050, 0054, 0065, 0134 |
| Akito | 0011 |
| Akura | 0001, 0032, 0050, 0054, 0134 |
| Alaron | 0048 |
| Alba | 0002, 0004, 0012, 0015, 0028, 0032, 0037, 0048, 0050, 0052, 0072, 0094, 0134 |
| ALBIRAL | 0013 |
| Alcyon | 0042 |
| Alkos | 0027 |
| Allorgan | 0049, 0056, 0070 |
| Allstar | 0014, 0134 |
| AMOi | 0151 |
| Amplivision | 0002, 0049, 0057, 0064, 0070, 0072 |
| Amstrad | 0001, 0004, 0032, 0050, 0073, 0134 |
| Anam | 0004, 0016 |
| Anglo | 0004, 0032 |
| Anhua | 0162 |
| Anitech | 0001, 0004, 0032, 0042, 0134 |
| Ansonic | 0004, 0005, 0032, 0035, 0044, 0052, 0053, 0055, 0072, 0134 |
| Aolinpiya | 0183 |
| Apollo | 0067 |
| Arc en Ciel | 0025, 0058 |
| Arcam | 0048, 0049, 0070 |
| Arcam Delta | 0002 |
| Aristona | 0014, 0028, 0035, 0134 |
| Arthur Martin | 0064 |
| ASA | 0000, 0006, 0007, 0009, 0040, 0061 |
| Asberg | 0014, 0042, 0134 |
| Astra | 0004 |
| Asuka | 0001, 0002, 0048, 0049, 0050, 0054, 0070 |
| Atlantic | 0002, 0014, 0028, 0048, 0053, 0057, 0134 |
| Atori | 0004, 0032 |
| Auchan | 0064 |
| Audiosonic | 0002, 0004, 0014, 0025, 0028, 0049, 0050, 0060, 0070, 0072, 0134 |
| AudioTon | 0002, 0049, 0070, 0072 |
| Ausind | 0042 |
| Autovox | 0000, 0001, 0002, 0042, 0049, 0052, 0062, 0070 |
| Awa | 0034, 0048, 0070 |
| Ayomi | 0051 |
| **B** | |
| Baihehua | 0182 |
| Baihua | 0181, 0183 |
| Baile | 0180, 0181 |
| Baird | 0025, 0041, 0046, 0049, 0070 |
| Bang & Olufsen | 0000, 0074 |
| BaoHuaShi | 0183 |
| Baosheng | 0179, 0181 |
| Basic Line | 0004, 0014, 0032, 0050, 0054, 0070, 0134 |
| Bastide | 0002, 0049, 0070 |
| Baur | 0026, 0028, 0033, 0062, 0081, 0134 |
| Bazin | 0049, 0070 |
| Beijing | 0169, 0179, 0180, 0181, 0182, 0183 |
| Beko | 0072, 0087, 0134 |
| Benq | 0141, 0192 |
| Beon | 0014, 0028, 0134 |
| Best | 0060, 0072 |
| Bestar | 0014, 0072, 0134 |
| Binatone | 0002, 0049, 0070 |
| Black Star | 0022, 0052 |
| Blacktron | 0054 |
| Blackway | 0054 |
| Blaupunkt | 0003, 0081 |
| Blue Sky | 0050, 0054, 0065, 0134 |
| Blue Star | 0020, 0054 |
| Bondstec | 0022, 0052 |
| Boots | 0002, 0011, 0049, 0070 |
| BPL | 0020, 0054, 0134 |
| Brandt | 0025, 0058, 0059, 0069, 0079 |
| Brinkmann | 0134 |
| Brionvega | 0000, 0014, 0028, 0134 |
| Britannia | 0002, 0048, 0049, 0070 |
| Bruns | 0000 |
| BSR | 0023, 0056 |
| BTC | 0050 |
| Bush | 0004, 0008, 0010, 0011, 0012, 0014, 0020, 0023, 0025, 0028, 0029, 0032, 0037, 0049, 0050, 0054, 0056, 0062, 0070, 0094, 0095, 0134 |
| **C** | |
| Cabletime | 0165 |
| Caihong | 0179, 0181 |
| Cailing | 0186 |
| Caixing | 0182 |
| Capsonic | 0001 |
| Carena | 0065, 0134 |
| Carrefour | 0012, 0037, 0040 |
| Cascade | 0004, 0032, 0134 |
| Casio | 0147 |
| Cathay | 0014, 0028, 0134 |
| CCE | 0070 |
| Centurion | 0014, 0028, 0134 |
| Century | 0000, 0052 |
| CGE | 0015, 0022, 0023, 0042, 0052, 0072 |
| Chang Cheng | 0162, 0169, 0179, 0180, 0181, 0182, 0183 |
| Changfei | 0179, 0181, 0188 |
| Changfeng | 0179, 0183 |
| Changhai | 0179, 0181, 0188 |
| Changhong | 0153, 0169, 0179, 0181 |
| Chaparral | 0160 |
| Chengdu | 0179 |
| Chimei | 0146 |
| Chunfeng | 0181, 0183 |
| Chunlan | 0189 |
| Chunsun | 0179, 0181 |
| Cimline | 0004, 0032, 0050 |
| City | 0004, 0032 |
| Clarivox | 0013, 0028 |
| Clatronic | 0001, 0002, 0004, 0014, 0022, 0032, 0042, 0044, 0049, 0050, 0052, 0057, 0070, 0072, 0134 |
| CMS | 0048 |
| CMS Hightec | 0070 |
| Concorde | 0004, 0032 |
| Condor | 0002, 0014, 0032, 0044, 0048, 0052, 0054, 0057, 0072, 0134 |
| Conrowa | 0181, 0183 |
| Contec | 0002, 0004, 0012, 0032, 0034, 0037, 0048 |
| Continental Edison | 0025, 0058 |
| Cosmel | 0004, 0032, 0060 |
| Crosley | 0000, 0022, 0023, 0042, 0052 |
| Crown | 0004, 0014, 0015, 0021, 0028, 0032, 0042, 0072, 0134 |
| CS Electronics | 0002, 0022, 0048, 0050, 0052 |
| CTC | 0022, 0052 |
| CTC Clatronic | 0005 |
| Cybertron | 0050 |
| **D** | |
| Daewoo | 0002, 0004, 0014, 0032, 0048, 0049, 0050,0070, 0091, 0115, 0123, 0134 |
| Dainichi | 0048, 0050 |
| Dansai | 0001, 0014, 0028, 0036, 0048, 0070, 0134 |
| Dantax | 0017, 0028, 0029, 0072 |
| Datsura | 0021 |
| Dawa | 0134 |
| Daytron | 0004, 0032 |
| Dayu | 0180 |
| De Graaf | 0008, 0039, 0108 |
| Decca | 0002, 0011, 0014, 0028, 0041, 0049, 0070,0073, 0134 |
| Denver | 0138, 0140 |
| Desmet | 0014, 0028, 0057, 0134 |
| Diamant | 0134 |
| Diamond | 0048 |
| Dixi | 0004, 0014, 0028, 0032, 0070, 0134 |
| DongBao | 0169 |
| DongDa | 0169, 0181 |
| Donghai | 0181 |
| DongHua | 0169 |
| DTS | 0004, 0032 |
| Dual | 0002, 0023, 0025, 0049, 0053, 0062, 0070, 0134 |
| Dual-Tec | 0002, 0004, 0023, 0049, 0053 |
| Dumont | 0000, 0002, 0005, 0007, 0040, 0044, 0049, 0070 |
| Dux | 0028 |
| Dynatron | 0014, 0028, 0134 |
| **E** | |
| Elbe | 0013, 0050, 0051, 0053, 0055, 0070, 0072, 0073, 0134 |
| Elbe-Sharp | 0073 |
| Elcit | 0000, 0044, 0052, 0073 |
| Electa | 0020 |
| ELECTRO TECH | 0004 |
| Elektra | 0054 |
| Elin | 0002, 0006, 0014, 0028, 0032, 0048, 0062, 0134 |
| Elite | 0014, 0050, 0134 |
| Elman | 0005, 0023, 0044 |
| Elta | 0004, 0032, 0048 |
| Emerson | 0000, 0026, 0040, 0052, 0072, 0134 |
| Emperor | 0054 |
| Epson | 0139 |
| Erres | 0014, 0028, 0035, 0134 |
| ESC | 0070 |
| Etron | 0004 |
| Eurofeel | 0001, 0070 |
| Euroline | 0017, 0028 |
| Euroman | 0001, 0002, 0014, 0048, 0049, 0054, 0070, 0072, 0134 |
| Europhon | 0002, 0005, 0011, 0014, 0023, 0044, 0048, 0049, 0052, 0070, 0073, 0134 |
| Expert | 0053, 0064 |
| Exquisit | 0134 |
| **F** | |
| Feilang | 0181 |
| Feilu | 0179, 0181 |
| Feiyan | 0183 |
| Feiyue | 0179, 0181, 0182 |
| Fenner | 0004, 0032 |
| Ferguson | 0013, 0028, 0046, 0051, 0059, 0069, 0079 |
| Fidelity | 0002, 0008, 0018, 0048, 0134 |
| Filmnet | 0157 |
| Filsai | 0070 |
| Finlandia | 0008, 0061, 0108 |
| Finlux | 0000, 0002, 0005, 0006, 0007, 0014, 0023, 0028, 0040, 0041, 0042, 0044, 0045, 0049, 0061, 0070, 0073, 0134 |
| Firstline | 0002, 0004, 0014, 0022, 0032, 0041, 0044, 0048, 0049, 0051, 0052, 0056, 0062, 0070, 0134 |
| Fisher | 0000, 0002, 0012, 0023, 0037, 0041, 0049, 0062, 0070, 0072, 0108 |
| Flint | 0014, 0041, 0050, 0065, 0134 |
| FNR | 0044 |
| Formenti | 0000, 0002, 0023, 0024, 0028, 0042, 0048, 0057 |
| Formenti-Phoenix | 0048, 0155 |
| Fortress | 0000, 0043 |
| Fraba | 0072, 0134 |
| France Telecom | 0167 |
| Friac | 0072 |
| Frontech | 0001, 0004, 0008, 0009, 0022, 0032, 0052, 0062, 0070 |
| Fujitsu | 0041, 0044, 0049, 0070 |
| Fujitsu General | 0070 |
| Funai | 0001, 0015, 0045, 0056 |
| **G** | |
| Galaxi | 0044, 0134 |
| Galaxis | 0044, 0072, 0134 |
| Ganxin | 0179, 0182 |
| GBC | 0004, 0012, 0023, 0032, 0050 |
| Geant Casino | 0064 |
| GEC | 0002, 0009, 0014, 0026, 0028, 0038, 0041, 0049, 0062, 0070, 0073, 0134 |
| Geloso | 0004, 0008, 0023, 0032, 0052 |
| General | 0066 |
| General Technic | 0004, 0032 |
| Genexxa | 0009, 0014, 0050, 0134 |
| Giant | 0070 |
| GoldHand | 0048 |
| Goldline | 0134 |
| GoldStar | 0002, 0004, 0008, 0014, 0022, 0023, 0028, 0029, 0032, 0048, 0049, 0052, 0070, 0071, 0072, 0134 |
| Goodmans | 0001, 0004, 0012, 0014, 0028, 0032, 0036, 0037, 0041, 0045, 0049, 0068, 0070, 0071, 0073, 0134 |
| Gorenje | 0072 |
| GPM | 0050 |
| Graetz | 0009, 0026 |
| Granada | 0002, 0008, 0012, 0014, 0024, 0028, 0035, 0037, 0041, 0042, 0049, 0059, 0063, 0064, 0067, 0070, 0073, 0108, 0134 |
| Grandin | 0004, 0020, 0028, 0054 |
| Gronic | 0070 |
| Grundig | 0003, 0007, 0040, 0042, 0072, 0081, 0134 |
| **H** | |
| Haier | 0076, 0187 |
| HaiHong | 0169 |
| Haiyan | 0179, 0182, 0183 |
| Halhong | 0181 |
| Halifax | 0001, 0002, 0048, 0049, 0070 |
| Hampton | 0002, 0048, 0049, 0070 |
| Hanseatic | 0002, 0004, 0012, 0014, 0023, 0026, 0028, 0032, 0049, 0054, 0055, 0056, 0057, 0062, 0070, 0072, 0134 |
| Hantarex | 0004, 0032, 0073, 0134 |
| Hantor | 0134 |
| Harwood | 0032, 0134 |
| Hauppauge | 0030 |
| HCM | 0001, 0002, 0004, 0020, 0032, 0049, 0050, 0054, 0070, 0134 |
| Hema | 0032, 0049, 0070 |
| Hemmermann | 0062 |
| Hifivox | 0025 |
| Higashi | 0048 |
| HiLine | 0134 |
| Hinari | 0004, 0012, 0014, 0028, 0032, 0037, 0045, 0050, 0108, 0134 |
| Hisawa | 0020, 0050, 0054, 0064, 0065 |
| Hisense | 0164 |
| Hitachi | 0002, 0006, 0008, 0009, 0012, 0023, 0024, 0025, 0026, 0037, 0038, 0039, 0041, 0049, 0062, 0063, 0067, 0070, 0073, 0117, 0119, 0123, 0134 |
| Hitch Fufian | 0164, 0179, 0182, 0183 |
| Hongmei | 0179, 0181, 0182, 0183 |
| Hongyan | 0179, 0183 |
| Hornyphon | 0014, 0134 |
| Hoshai | 0050, 0065 |
| Huafa | 0181 |
| Huanghaimei | 0181 |
| Huanghe | 0179, 0181, 0182 |
| Huanglong | 0181 |
| Huangshan | 0179, 0181, 0182, 0183 |
| Huanyu | 0002, 0048, 0164, 0179, 0182, 0183 |
| Huaqiang | 0183 |
| Huari | 0183 |
| Huodateji | 0162 |
| Hygashi | 0002, 0048, 0049, 0070 |
| Hyper | 0002, 0004, 0022, 0023, 0032, 0048, 0049, 0052, 0070 |
| Hypson | 0001, 0002, 0014, 0020, 0028, 0049, 0054, 0064, 0065, 0070, 0134 |
| Hyundai | 0077 |
| **I** | |
| Iberia | 0134 |
| ICE | 0001, 0002, 0004, 0014, 0032, 0048, 0049, 0050, 0070, 0134 |
| ICeS | 0048, 0050 |
| Imperial | 0009, 0014, 0015, 0022, 0023, 0042, 0052, 0062, 0072, 0134 |
| Imperial Cown | 0180, 0183 |
| Indesit | 0010 |
| Indiana | 0014, 0028, 0134 |
| Ingelen | 0009 |
| Ingersol | 0004, 0032 |
| Inno Hit | 0002, 0004, 0014, 0028, 0032, 0041, 0042, 0049, 0050, 0052, 0070, 0071, 0073, 0134 |
| Innovation | 0001, 0004, 0029 |
| INTER | 0174 |
| Interactive | 0072 |
| Interbuy | 0004, 0022, 0032, 0052 |
| Interfunk | 0000, 0009, 0014, 0022, 0025, 0026, 0028, 0035, 0072, 0134 |
| International | 0048 |
| Intervision | 0001, 0002, 0005, 0044, 0049, 0050, 0052, 0054, 0065, 0070, 0072, 0134 |
| Irradio | 0004, 0014, 0028, 0032, 0042, 0050, 0052, 0071, 0134 |
| Isukai | 0050, 0054, 0134 |
| IT | 0172 |
| ITC | 0002, 0023, 0049, 0070 |
| ITS | 0014, 0020, 0048, 0050, 0054, 0134 |
| ITT | 0004, 0009, 0024, 0026, 0045, 0061, 0062, 0067, 0068 |
| ITV | 0004, 0017, 0028, 0029, 0052, 0134 |
| **J** | |
| JEC | 0027, 0036 |
| Jiahua | 0162 |
| JiaLiCai | 0169, 0181, 0183 |
| Jinfeng | 0162, 0179 |
| Jinque | 0179, 0181, 0183 |
| Jinta | 0181, 0182, 0183 |
| Jinxing | 0179, 0183 |
| Juhua | 0179, 0182, 0183 |
| JVC | 0012, 0014, 0037, 0046, 0050, 0118, 0211, 0212 |
| **K** | |
| Kaige | 0179, 0181, 0182, 0183 |
| Kaisui | 0002, 0004, 0020, 0032, 0048, 0049, 0050, 0054, 0065, 0070, 0134 |
| Kamosonic | 0002 |
| Kamp | 0002, 0048 |
| Kangli | 0179, 0180, 0181, 0182, 0183 |
| Kangyi | 0181, 0183 |
| KanLi | 0169 |
| KanYi | 0168 |
| Kapsch | 0009, 0053 |
| Karcher | 0002, 0004, 0006, 0013, 0028, 0044, 0054, 0072, 0134 |
| Kawasho | 0048 |
| Kendo | 0005, 0008, 0044, 0052, 0072, 0134 |
| Kennedy | 0023 |
| KIC | 0070 |
| Kingsley | 0002, 0048 |
| Kneissel | 0051, 0053, 0055, 0072, 0134 |
| Kolster | 0014, 0134 |
| Kongque | 0179, 0181, 0182, 0183 |
| Konka | 0050 |
| Korpel | 0014, 0028, 0134 |
| Korting | 0000, 0057, 0072 |
| Kosmos | 0134 |
| Koyoda | 0004 |
| KTV | 0002, 0070 |
| Kuaile | 0181, 0183 |
| Kunlun | 0162, 0179, 0180, 0183 |
| Kuro | 0021 |
| Kyoto | 0013, 0048, 0070 |
| **L** | |
| Lasat | 0072 |
| Lenco | 0004, 0032 |
| Lenoir | 0002, 0004, 0032 |
| Lesa | 0022, 0052 |
| Leyco | 0001, 0014, 0028, 0041, 0056, 0134 |
| LG | 0002, 0004, 0008, 0014, 0017, 0022, 0023, 0028, 0029, 0032, 0048, 0049, 0052, 0070, 0071, 0072, 0110, 0128, 0134, 0137, 0193, 0205, 0214 |
| Liesenk | 0028 |
| Liesenkotter | 134 |
| Life | 0001, 0004, 0029 |
| Lifetec | 0001, 0004, 0029, 0032, 0050, 0134 |
| Lihua | 0179 |
| Lloyds | 0032 |
| Loewe | 0055, 0072, 0073, 0082, 0083, 0122, 0134 |
| Loewe Opta | 0000, 0014, 0028 |
| Logik | 0034 |
| Longjiang | 0179, 0183 |
| Luma | 0008, 0026, 0028, 0032, 0053, 0134 |
| Lumatron | 0008, 0014, 0026, 0028, 0049, 0053, 0070, 0134 |
| Lux May | 0014 |
| Luxor | 0002, 0008, 0026, 0062, 0063, 0068, 0070, 0071 |
| **M** | |
| M Electronic | 0002, 0004, 0006, 0009, 0014, 0025, 0028, 0032, 0048, 0049, 0052, 0061, 0068, 0070, 0134 |
| Magnadyne | 0000, 0005, 0022, 0023, 0028, 0044, 0052, 0073 |
| Magnafon | 0002, 0005, 0042, 0044, 0048, 0073 |
| Magnum | 0001, 0004, 0029 |
| Mandor | 0001 |
| Manesth | 0001, 0002, 0014, 0028, 0036, 0049, 0056, 0057, 0070, 0134 |
| Marantz | 0014, 0028, 0134 |
| Marelli | 0000 |
| Mark | 0014, 0028, 0032, 0048, 0049, 0070, 0134 |
| Masuda | 0070 |
| Matsui | 0002, 0004, 0008, 0011, 0012, 0014, 0027, 0028, 0032, 0034, 0036, 0037, 0041, 0049, 0056, 0059, 0062, 0065, 0070, 0073, 0081, 0134, 0145 |
| Matsushita | 0016 |
| McMichael | 0038 |
| Mediator | 0014, 0028, 0035, 0134 |
| Medion | 0001, 0004, 0029, 0134 |
| Meile | 0179, 0182, 0183 |
| MeiShi | 0168 |
| Melvox | 0064 |
| Memorex | 0004, 0032 |
| Memphis | 0004, 0032, 0041, 0060 |
| Mengmei | 0182 |
| Mercury | 0032, 0134 |
| Metz | 0000, 0081 |
| Micromaxx | 0001, 0004, 0029 |
| Microstar | 0001, 0004, 0029 |
| Minerva | 0007, 0040, 0042, 0073, 0081 |
| Minoka | 0014, 0134 |
| Mitsubishi | 0000, 0012, 0014, 0037, 0134 |
| Mivar | 0002, 0042, 0048, 0055, 0070, 0071, 0072, 0073 |
| MoDeng | 0168 |
| Motion | 0042 |
| MTC | 0048, 0062, 0072 |
| MuDan | 0162, 0179, 0181, 0183 |
| Multistandard | 0044 |
| Multisystem | 0028, 0155 |
| Multitech | 0002, 0004, 0005, 0008, 0012, 0022, 0023, 0028, 0032, 0044, 0048, 0049, 0052, 0062, 0070, 0072, 0134 |
| Murphy | 0002, 0024, 0041, 0048 |
| **N** | |
| NAD | 0026 |
| Naiko | 0019 |
| Nanbao | 0181, 0183 |
| Nansheng | 0179, 0183 |
| Naonis | 0008 |
| National | 0047 |
| NEC | 0012, 0037, 0057, 0070 |
| Neckermann | 0000, 0002, 0003, 0008, 0014, 0028, 0033, 0049, 0052, 0062, 0070, 0072, 0134 |
| NEI | 0014, 0028, 0060, 0134 |
| Nesco | 0022, 0045, 0052 |
| Network | 0060 |
| Neufunk | 0032, 0134 |
| New Tech | 0004, 0014, 0032, 0049, 0070, 0134 |
| New World | 0050 |
| Nicamagic | 0002, 0048 |
| Nikkai | 0001, 0002, 0014, 0027, 0028, 0032, 0036, 0037, 0041, 0048, 0049, 0050, 0060, 0070, 0134 |
| Nobliko | 0002, 0005, 0007, 0040, 0042, 0044, 0048 |
| Nogamatic | 0025 |
| Nokia | 0009, 0024, 0026, 0061, 0062, 0067, 0068 |
| Nordic | 0070 |
| Nordmende | 0000, 0009, 0010, 0014, 0025, 0081 |
| Nordvision | 0028 |
| Novatronic | 0134 |
| **O** | |
| Oceanic | 0009, 0026, 0056, 0064 |
| Okano | 0041, 0072, 0134 |
| ONCEAS | 0002 |
| Onwa | 0050 |
| Opera | 0134 |
| Orbit | 0014, 0134 |
| Orion | 0004, 0014, 0019, 0028, 0029, 0032, 0034, 0044, 0056, 0057, 0073, 0124, 0134 |
| Orline | 0050, 0134 |
| Ormond | 0029 |
| Orsowe | 0073 |
| Osaki | 0001, 0002, 0041, 0049, 0050, 0070, 0134 |
| Osio | 0071 |
| Oso | 0050 |
| Osume | 0037, 0041, 0050 |
| Other Brand | 0184 |
| Others | 0158 |
| Otto Versand | 0002, 0003, 0012, 0014, 0020, 0021, 0023, 0025, 0026, 0028, 0033, 0037, 0043, 0049, 0052, 0056, 0057, 0062, 0070, 0073, 0081, 0134 |
| **P** | |
| Pael | 0002, 0048 |
| Palladium | 0002, 0033, 0049, 0052, 0062, 0070, 0072, 0134 |
| Palsonic | 0070 |
| Panama | 0001, 0002, 0004, 0032, 0048, 0049, 0052, 0070, 0134 |
| Panasonic | 0009, 0016, 0026, 0047, 0073, 0092, 0111, 0130, 0134, 0194, 0217, 0218, 0219, 0220 |
| Panavision | 0134 |
| Panda | 0162, 0179, 0181, 0182, 0183 |
| Pathe Cinema | 0002, 0013, 0023, 0048, 0051, 0055, 0057, 0062, 0064, 0072 |
| Pathe Marconi | 0013, 0025, 0058 |
| Pausa | 0004, 0032 |
| Pensonic | 0150 |
| Perdio | 0041, 0048, 0057, 0134 |
| Perfekt | 0134 |
| Philco | 0000, 0015, 0022, 0023, 0042, 0052, 0072, 0134 |
| Philharmonic | 0002, 0049, 0070 |
| Philips | 0000, 0002, 0014, 0017, 0023, 0026, 0028, 0035, 0038, 0078, 0080, 0086, 0096, 0097, 0098, 0101, 0106, 0107, 0121, 0125, 0126, 0129, 0133, 0134 |
| Phoenix | 0000, 0014, 0028, 0041, 0048, 0057, 0072, 0134 |
| Phonola | 0000, 0014, 0028, 0035, 0048, 0134 |
| Pilot | 0171, 0173, 0175, 0176, 0177, 0178 |
| Pioneer | 0009, 0014, 0025, 0028, 0072, 0134 |
| Plantron | 0001, 0014, 0032, 0134 |
| Playsonic | 0049, 0070 |
| Polestar | 0159 |
| Poppy | 0004, 0032 |
| Prandoni-Prince | 0008, 0026, 0042, 0052, 0073 |
| Praxis | 0161 |
| Precision | 0002, 0049, 0070 |
| Prima | 0004, 0009, 0032 |
| Prinz | 0041, 0062 |
| Profex | 0004, 0026, 0032 |
| Profilo | 0029 |
| Profi-Tronic | 0014, 0044, 0134 |
| Proline | 0014, 0035, 0041, 0134 |
| Promac | 0149, 0195 |
| Prosonic | 0002, 0028, 0029, 0047, 0048, 0070, 0072, 0134 |
| Protech | 0001, 0002, 0004, 0005, 0014, 0022, 0023, 0028, 0070 |
| Provision | 0028, 0029, 0134 |
| Pye | 0014, 0028, 0035, 0096, 0134 |
| Pymi | 0004, 0032 |
| **Q** | |
| Qingdao | 0162, 0179, 0183 |
| Quandra Vision | 0064 |
| Quasar | 0022 |
| Quelie | 0154 |
| Quelle | 0001, 0002, 0006, 0007, 0014, 0022, 0023, 0026, 0028, 0029, 0033, 0034, 0037, 0040, 0049, 0052, 0062, 0070, 0071, 0081, 0134 |
| Questa | 0012, 0037 |
| **R** | |
| Radialva | 0050, 0134 |
| Radio Shack | 0134 |
| Radiola | 0014, 0028, 0035, 0070, 0134 |
| Radiomarelli | 0000, 0022, 0052, 0073, 0134 |
| RADIONETTE | 0006 |
| Radiotone | 0014, 0032, 0072, 0134 |
| Rank | 0007, 0012, 0040 |
| RBM | 0007 |
| Recor | 0134 |
| Rediffusion | 0026 |
| Redstar | 0134 |
| Reflex | 0134 |
| Revox | 0014, 0028, 0072, 0134 |
| Rex | 0001, 0008, 0009, 0052, 0053 |
| RFT | 0000, 0041, 0055, 0072 |
| Rhapsody | 0048 |
| R-Line | 0014, 0028, 0134 |
| Roadstar | 0001, 0004, 0032, 0050 |
| Robotron | 0000 |
| Rowa | 0048, 0070 |
| Royal Lux | 0072 |
| RTF | 0000 |
| Ruyi | 0164, 0179, 0182 |
| **S** | |
| Saba | 0000, 0009, 0025, 0026, 0059, 0069, 0073, 0079 |
| saccs | 0013 |
| Sagem | 0065 |
| Saige | 0179, 0181 |
| Saisho | 0001, 0002, 0004, 0032, 0034, 0049, 0070, 0073 |
| Salora | 0008, 0009, 0021, 0023, 0026, 0062, 0063, 0071, 0073 |
| Sambers | 0005, 0042, 0044, 0073 |
| Samsung | 0001, 0002, 0004, 0014, 0028, 0032, 0041, 0048, 0049, 0070, 0071, 0072, 0085, 0088, 0090, 0094, 0114, 0127, 0131, 0134 |
| Sandra | 0002, 0048, 0049, 0070 |
| Sanjian | 0183 |
| Sansui | 0014, 0134 |
| Sanyo | 0002, 0006, 0012, 0023, 0032, 0034, 0037, 0041, 0048, 0049, 0055, 0070, 0072, 0108 |
| Sanyuan | 0179, 0181, 0182 |
| SBR | 0028, 0035, 0134 |
| Schaub Lorenz | 0009, 0026, 0062 |
| Schneider | 0002, 0014, 0023, 0025, 0028, 0035, 0049, 0050, 0052, 0053, 0062, 0070, 0134 |
| SEG | 0001, 0002, 0005, 0012, 0017, 0022, 0023, 0028, 0032, 0037, 0048, 0049, 0052, 0070, 0113, 0134 |
| SEI | 0033, 0044, 0056, 0062, 0073, 0134 |
| SEI-Sinudyne | 0000, 0005, 0009, 0073 |
| Seleco | 0008, 0009, 0012, 0023, 0053 |
| Sencora | 0004, 0032 |
| Sentra | 0027, 0032, 0036, 0050 |
| Serino | 0048, 0065 |
| Shancha | 0179, 0183 |
| Shangguangdian | 0190 |
| Shanghai | 0179, 0181, 0182, 0183, 0188 |
| Shaofeng | 0164, 0179, 0182 |
| Sharp | 0012, 0037, 0043, 0056, 0073, 0084, 0099, 0105, 0112, 0116, 0135, 0191, 0206, 0207, 0209 |
| Shencai | 0181, 0183 |
| ShengCai | 0169 |
| Shengli | 0163 |
| Shenyang | 0179, 0181, 0183 |
| Sherwood | 0181 |
| Shorai | 0045, 0056 |
| Siarem | 0000, 0005, 0023, 0044, 0073, 0081, 0134 |
| Sicatel | 0013 |
| Siemens | 0003 |
| Sierra | 0014, 0035, 0134 |
| Siesta | 0072 |
| Silva | 0048 |
| Silver | 0012, 0037, 0045 |
| Singer | 0000, 0005, 0022, 0023, 0044, 0052, 0064 |
| Sinudyne | 0000, 0005, 0023, 0028, 0033, 0044, 0056, 0062, 0073, 0134 |
| Skantic | 0009, 0063 |
| Skyworth | 0031, 0179, 0183 |
| Sogera | 0057 |
| Solavox | 0009, 0041 |
| Songbai | 0181 |
| SongRi | 0169 |
| Sonitron | 0049, 0070, 0072, 0108 |
| Sonoko | 0001, 0002, 0004, 0014, 0028, 0032, 0049, 0054, 0070, 0134 |
| Sonolor | 0009, 0033, 0064, 0108 |
| Sontec | 0014, 0028, 0056, 0072, 0134 |
| Sony | 0004, 0012, 0033, 0034, 0037, 0044, 0100, 0103, 0109, 0120, 0132, 0196, 0197, 0198, 0199, 0200, 0201, 0202, 0203, 0204, 0208, 0210, 0213, 0215, 0216 |
| Sound & Vision | 0005, 0044, 0050 |
| Soundwave | 0014, 0028, 0057, 0134 |
| Standard | 0002, 0004, 0014, 0032, 0049, 0050, 0057, 0070, 0134 |
| Starlite | 0028, 0032, 0134 |
| Stenway | 0020, 0050, 0054 |
| Stern | 0008, 0009, 0053 |
| Strato | 0032, 0134 |
| Stylandia | 0070 |
| Sunkai | 0004, 0050, 0056, 0065 |
| Sunstar | 0032, 0134 |
| Sunwood | 0004, 0014, 0032, 0134 |
| Superla | 0002, 0048, 0070, 0073 |
| SuperTech | 0032, 0048, 0134 |
| Supra | 0004, 0032 |
| Susumu | 0059 |
| Sutron | 0004, 0032 |
| Sydney | 0002, 0048, 0049, 0070 |
| Sysline | 0028 |
| Sytong | 0048 |
| **T** | |
| Taishan | 0179, 0181 |
| Tandberg | 0060 |
| Tandy | 0002, 0009, 0024, 0041, 0043, 0049, 0050, 0052, 0070 |
| Tantec | 0011 |
| Tashiko | 0002, 0008, 0012, 0037, 0038, 0048, 0049, 0070 |
| Tatung | 0002, 0011, 0014, 0028, 0034, 0041, 0049, 0070, 0073, 0134 |
| TCL | 0185 |
| TCM | 0001, 0004, 0029, 0075 |
| Teac | 0065, 0070, 0134 |
| Tec | 0002, 0004, 0022, 0023, 0024, 0032, 0049, 0052, 0059, 0060, 066, 0070 |
| Technema | 0057 |
| Technics | 0016 |
| Technovision | 0166 |
| TEDELEX | 0070 |
| Teleavia | 0025, 0058 |
| Telecor | 0049, 0050, 0053, 0070, 0134 |
| Telefunken | 0014, 0025, 0059, 0066, 0134 |
| Telegazi | 0050, 0053, 0134 |
| Telemeister | 057, 0134 |
| Teleservice | 0165 |
| Telesonic | 0134 |
| Telestar | 0134 |
| Teletech | 0004, 0017, 0022, 0028, 0032, 0052, 0060, 0134 |
| Teleton | 0002, 0037, 0049, 0053, 0062, 0070 |
| Televideon | 0048, 0057 |
| Televiso | 0064 |
| Temco | 0056 |
| Tensai | 0004, 0014, 0032, 0049, 0050, 0052, 0056, 0057, 0070, 0134 |
| Tenson | 0057 |
| Tesmet | 0014 |
| Tevion | 0001, 0004, 0029 |
| Texet | 0002, 0032, 0048, 0049, 0070 |
| Thomson | 0002, 0014, 0025, 0058, 0059, 0066, 0069, 0079, 0093, 0134 |
| Thorn | 0013, 0026, 0027, 0028, 0046, 0051, 0059, 0134 |
| Tiane | 0179 |
| Tobo | 0181, 0183 |
| Tokai | 014, 0041, 0049, 0060, 0070, 0134 |
| Tokyo | 0002, 0036, 0048 |
| Tomashi | 0020, 0054 |
| Tongguang | 0183 |
| Toshiba | 0007, 0012, 0027, 0036, 0037, 0040, 0044, 0070, 0089, 0102, 0104, 0136 |
| Towada | 0009, 0023, 0044, 0062, 0070 |
| Trakton | 0070 |
| Trans Continens | 0049, 0070, 0134 |
| Transtec | 0048 |
| Trident | 0049, 0070, 0073 |
| Tristar | 0050 |
| Triumph | 0061, 0073, 0134 |
| **U** | |
| Uher | 0009, 0014, 0042, 0053, 0057, 0072, 0134 |
| Ultravox | 0000, 0002, 0005, 0022, 0023, 0024, 0044, 0048, 0052, 0134 |
| Unic Line | 0067, 0134 |
| Union | 0148 |
| United | 0017, 0028 |
| Universum | 0001, 0006, 0014, 0022, 0023, 0028, 0033, 0034, 0037, 0040, 0042, 0049, 0052, 0056, 0060, 0061, 0062, 0067, 0068, 0070, 0071, 0072, 0081, 0134 |
| Univox | 0013, 0051, 0060, 0134 |
| **V** | |
| Vegavox | 0156 |
| Vestel | 0008, 0009, 0014, 0022, 0023, 0028, 0029, 0049, 0070, 0134 |
| Vexa | 0004, 0028, 0032, 0134 |
| Victor | 0012, 0014, 0016 |
| Videocon | 0153 |
| VIDEOLOGIC | 0048 |
| Videologique | 0002, 0048, 0049, 0050, 0070 |
| Videosat | 0022 |
| VideoSystem | 0014, 0134 |
| Videotechnic | 0048, 0049, 0057, 0070 |
| Videoton | 0063 |
| Viewsonic | 0143, 0144 |
| Visiola | 0002, 0048 |
| Vision | 0014, 0057, 0070, 0134 |
| Visorex | 0018 |
| Vistar | 0024 |
| Vortec | 0014, 0028, 0134 |
| Voxson | 0000, 0008, 0009, 0014, 0042, 0134 |
| **W** | |
| Waltham | 0002, 0013, 0024, 0049, 0063, 0070, 0134 |
| Warumaia | 0180 |
| Watson | 0014, 0028, 0050, 0057, 0134 |
| Watt Radio | 0002, 0005, 0013, 0023, 0044, 0048, 0062 |
| Wega | 0000, 0012, 0037, 0134 |
| Wega Color | 0152 |
| Wegavox | 0032 |
| Weipai | 0181 |
| Weltblick | 0014, 0028, 0057, 0070, 0134 |
| Weston | 0023 |
| Wharfedale | 0019 |
| White Westinghouse | 0002, 0005, 0028, 0048, 0057, 0060, 0134 |
| Windstar | 0054 |
| **X** | |
| Xiahua | 0179, 0181, 0183 |
| Xiangyang | 0183 |
| Xiangyu | 0181 |
| Xihu | 0179, 0182, 0183 |
| Xinaghai | 0181, 0183 |
| Xingfu | 0181 |
| Xinsida | 0188 |
| Xrypton | 0134 |
| Xuelian | 0182 |
| **Y** | |
| Yamaha | 0142 |
| Yamishi | 0049, 0050, 0054, 0065, 0070, 0134 |
| YingGe | 0169, 0181, 0182 |
| Yokan | 0134 |
| Yoko | 0001, 0002, 0004, 0014, 0028, 0032, 0048, 0049, 0050, 0070, 0072, 0134 |
| Yonggu | 0181, 0182 |
| Yorx | 0050 |
| Youlanasi | 0179, 0182 |
| Yousida | 0181 |
| Yuhang | 0181 |
| **Z** | |
| Zanussi | 0008, 0049, 0070 |
| Zhuhai | 0181 |

### DVD CODES

| | |
|---|---|
| **A** | |
| Aiwa | 1122 |
| Akai | 1007 |
| Akura | 1040 |
| Alba | 1063, 1069, 1089, 1096, 1108 |
| AMOi | 1140 |
| Amoisonic | 1185 |
| Apex | 1017 |
| ATLM | 1148 |
| **B** | |
| Bang & Olufsen | 1043 |
| BBK | 1179 |
| Best Buy | 1036 |
| Bosston | 1030 |
| Brand | 1164 |
| Brandt | 1022, 1058, 1097 |
| Britannia | 1026 |
| Bush | 1023, 1025, 1034, 1038, 1070, 1108, 1123 |
| **C** | |
| Caini | 1192 |
| Caixing | 1171 |
| Cambridge Audio | 1028 |
| Caravell | 1141 |
| CAT | 1031, 1032 |
| Centrex | 1116 |
| Centrum | 1032 |
| CGV | 1028 |
| Changhong | 1181 |
| CineVision | 1037 |
| Classic | 1014 |
| Clatronic | 1034 |
| Conia | 1023 |
| Conic | 1149 |
| Crown | 1097 |
| Crypto | 1039 |
| C-Tech | 1029 |
| CyberHome | 1052, 1088, 1114 |
| **D** | |
| Daewoo | 1002, 1130 |
| Dalton | 1042 |
| Dansai | 1027, 1130 |
| Daytek | 1054, 1083 |
| Dayu | 1170 |
| DCS | 1142 |
| DEC | 1034 |
| Denca | 1146 |
| Denon | 1045, 1129, 1131 |
| Denver | 1034, 1040, 1132 |
| Denzel | 1024 |
| Desay | 1033 |
| Diamond | 1028, 1029 |
| Digitor | 1041 |
| Dihe | 1166, 1183 |
| DK Digital | 1084 |
| Dmtech | 1001 |
| Doda | 1176 |
| Dongan | 1180 |
| Dongpeng | 1191 |
| Dual | 1024 |
| DVX | 1029 |
| **E** | |
| Easy Home | 1036 |
| Eclipse | 1028 |
| Elta | 1003, 1107 |
| Emerson | 1011 |
| Enzer | 1024 |
| **F** | |
| Finlux | 1028 |
| Fisher | 1012 |
| **G** | |
| Gericom | 1116 |
| Global Solutions | 1029 |
| Global Sphere | 1029 |
| Go Video | 1005 |
| GoldStar | 1062 |
| Goodmans | 1034, 1038, 1116 |
| Graetz | 1024 |
| Grundig | 1008, 1116, 1121 |
| **H** | |
| H&B | 1034, 1035 |
| Haaz | 1028, 1029 |
| Haitai | 1143 |
| Haoji | 1165 |
| HiMAX | 1036 |
| Hitachi | 1005, 1016, 1024, 1036, 1056, 1063, 1210, 1213 |
| Huabao | 1156 |
| Hyundai | 1139 |
| **I** | |
| Idall | 1186 |
| Innovation | 1009, 1010, 1016 |
| **J** | |
| Jeutech | 1030 |
| Jiabao | 1200 |
| Jieke | 1172 |
| Jinge | 1184 |
| Jingewangpai | 1156 |
| Jinwang | 1158 |
| JVC | 1022, 1066, 1092, 1103, 1113, 1120, 1125, 1207 |
| JX2026G | 1201 |
| **K** | |
| Kenwood | 1117, 1168, 1182 |
| Ketai | 1157 |
| Kingavon | 1034 |
| Kiss | 1024, 1035 |
| Koda | 1034 |
| Kongque | 1196 |
| KXD | 1036 |
| **L** | |
| Lawson | 1029 |
| Lecson | 1027 |
| Legend-V | 1144 |
| Lenco | 1034 |
| LG | 1011, 1057, 1062, 1071, 1087, 1106, 1212 |
| Life | 1009, 1010 |
| Lifetec | 1009, 1010, 1016 |
| Limit | 1029 |
| Linshuma | 1159 |
| Loewe | 1008 |
| LogicLab | 1029 |
| Luxor | 1116 |
| **M** | |
| Magnavox | 1022, 1034, 1046 |
| Magnum | 1016 |
| Malanshi | 1190 |
| Malata | 1151, 1178 |
| Marantz | 1013, 1128 |
| Matsui | 1097 |
| Maxview | 1147 |
| MBO | 1020 |
| Mediencom | 1026 |
| Medion | 1009, 1010, 1016, 1038 |
| Metz | 1006 |
| MiCO | 1028 |
| Micromaxx | 1009, 1010, 1016 |
| Micromedia | 1022 |
| Micromega | 1048 |
| Microstar | 1009, 1010, 1016 |
| Mirror | 1038 |
| Mizuda | 1034, 1036 |
| Monyka | 1024 |
| Mustek | 1014, 1050 |
| Mx Onda | 1028 |
| **N** | |
| NAD | 1019 |
| Naiko | 1116 |
| Nakamichi | 1021 |
| Neufunk | 1024 |
| Next Base | 1138 |
| Nintaus | 1194 |
| NU-TEC | 1023 |
| **O** | |
| Okon | 1167 |
| Omni | 1026 |
| Onkyo | 1022, 1046, 1133 |
| Optim | 1027 |
| Orava | 1034 |
| Oritron | 1010 |
| Other Brand | 1153, 1180 |
| **P** | |
| P&B | 1034 |
| Pacific | 1029 |
| Palsonic | 1025 |
| Panasonic | 1045, 1059, 1061, 1068, 1077, 1078, 1079, 1086, 1215 |
| Panda | 1160, 1199 |
| Pensonic | 1137 |
| Philips | 1004, 1008, 1013, 1022, 1046, 1048, 1049, 1064, 1065, 1075, 1076, 1080, 1081, 1082, 1091, 1095, 1104, 1112, 1124, 1127, 1128 |
| Philips Magnavox | 1004 |
| Pioneer | 1006, 1055, 1060, 1109, 1110, 1111 |
| Proline | 1116 |
| Promac | 1136 |
| Provision | 1034 |
| **Q** | |
| Qinghuatongfang | 1163 |
| Qisheng | 1152, 1174 |
| Qixing | 1173 |
| **R** | |
| Raite | 1024 |
| REC | 1025, 1026 |
| RedStar | 1040 |
| Reoc | 1029 |
| Revoy | 1035 |
| Risheng | 1198 |
| Roadstar | 1025, 1034 |
| Rowa | 1023, 1116, 1186 |
| Rownsonic | 1032 |
| **S** | |
| Saba | 1058, 1097 |
| Sabaki | 1029 |
| Sampo | 1015 |
| Samsung | 1005, 1056, 1094 |
| Sansui | 1028, 1029 |
| Sanyo | 1098, 1105 |
| Sast | 1154, 1187 |
| ScanMagic | 1050 |
| Schneider | 1000, 1001, 1010 |
| Scientific Labs | 1029 |
| Scott | 1042, 1067 |
| SEG | 1000, 1024, 1029, 1063, 1093, 1206 |
| Shanshui | 1155, 1203 |
| Sharp | 1009, 1019, 1102 |
| Sherwood | 1018 |
| Shinco | 1177 |
| Sigmatek | 1036 |
| Silva | 1040 |
| Singer | 1028, 1029 |
| Skymaster | 1014, 1029 |
| Skyworth | 1040, 1156, 1205 |
| SM Electronic | 1029 |
| SMC | 1189 |
| Sony | 1053, 1072, 1073, 1074, 1085, 1090, 1099, 1100, 1101, 1119, 1126 |
| Soundmaster | 1029 |
| Soundmax | 1029 |
| Standard | 1029 |
| Star Cluster | 1029 |
| Starmedia | 1034 |
| Subor | 1202 |
| Supervision | 1029 |
| Synn | 1029 |
| Tatung | 1130, 1145 |
| **T** | |
| TCL | 1150, 1197 |
| TCM | 1009, 1010, 1016, 1044 |
| Teac | 1006, 1023, 1029 |
| Tec | 1040 |
| Technics | 1045 |
| Telefunken | 1032 |
| Tevion | 1009, 1010, 1016, 1029, 1042 |
| Thakral | 1195 |
| Thomson | 1047, 1058 |
| Tokai | 1024, 1040 |
| Toshiba | 1004, 1022, 1046, 1051, 1115, 1135, 1209, 1211, 1214 |
| TruVision | 1036 |
| **V** | |
| VCD3.0 | 1204 |
| Victom | 1193 |
| Victor | 1161 |
| Vtrek | 1039 |
| **W** | |
| Weifa | 1162 |
| Wharfedale | 1028, 1029 |
| Wintel | 1030 |
| **X** | |
| Xbox | 1047 |
| Xenon | 1134 |
| Xindai | 1169 |
| Xlogic | 1029 |
| XMS | 1025 |
| **Y** | |
| Yakumo | 1116 |
| Yamada | 1116 |
| Yamaha | 1045, 1048, 1208 |
| Yamakawa | 1024 |
| Yingzhibao | 1175 |
| Yukai | 1050, 1118 |
| **Z** | |
| Zaowei | 1188 |
| Zenith | 1011, 1022, 1046 |